
1 Carefully drill 2 x 6mm (1/4") diameter holes if using wall plugs OR 12mm (1/2") holes if using wall toggles, with a vertical distance of 15mm (5/8") between the holes.

Insert 2 wall toggles (drywall) OR wall plugs (brick) into holes.

2 Attach the Mounting Bracket to the wall and insert screws.

Fasten screws tightly.

3 Place Hand Towel Holder onto mounting bracket and fasten grub screw tightly.

English

4 Ensure Hand Towel Holder is tightly fastened to the wall.
