

English

1 Carefully drill 2 x 6mm (1/4") diameter holes through the wall with a distance of 165mm (6-1/2") between the holes.

Insert 2 x drywall anchors (drywall) or wall plugs (brick) into holes.

2 Insert Soap Dish onto wall and insert screws with a screwdriver, fastening tightly.

Ensure the Soap Dish is level.

3 Place end caps over Soap Dish flanges.

4 Ensure Soap Dish is tightly fastened to the wall.

Español

1 Taladrar cuidadosamente 2 agujeros de 6mm (1/4") de diámetro en la pared a 165mm (6-1/2") de distancia.

Introducir 2 anclajes (placa de yeso) o tarugos (pared de ladrillo) en los agujeros.

2 Ubicar la jabonera sobre la pared e introducir los tornillos con un destornillados, ajustándolos bien.

Asegurarse de que la jabonera esté nivelada.

Español

3 Colocar las tapas de los extremos sobre las bridas de la jabonera.

4 Asegurarse de que la jabonera esté bien sujeta a la pared.

Français

1 Percez avec précaution à travers la cloison deux trous de diamètre 6 mm (1/4") à une distance de 165 mm (6-1/2") entre les trous.

Insérez deux ancrages pour cloison sèche (cloison sèche) ou deux chevilles (brique) dans les trous.

2 Placez le porte-savon contre la cloison, insérez les vis à l'aide d'un tournevis et serrez bien.

Assurez-vous que le porte-savon est bien horizontal.

Français

3 Emboîtez les deux capuchons d'extrémité sur les pattes de fixation du porte-savon.

4 Assurez-vous que le porte-savon est bien fixé à la cloison.
