
1 Carefully drill 1 x 6mm (1/4") diameter hole through the wall at desired height.

Insert 1 x drywall anchor (drywall) or wall plug (brick) into holes.

2 Insert Robe Hook onto wall, aligning with the drilled hole, and screw in tightly.

3 Place end cap over the Robe Hook.

4 Ensure Robe Hook is tightly fastened to the wall.

Español

1 Taladrar cuidadosamente 1 agujero de 6mm (1/4") de diámetro en la pared a la altura deseada.

Introducir 1 anclaje (placa de yeso) o tarugo (pared de ladrillo) en el agujero.

2 Ubicar el gancho para ropa sobre la pared, alineándolo con el agujero, y atornillarlo bien.

3 Colocar la tapa del extremo sobre el gancho.

4 Asegurarse de que el gancho para ropa esté bien sujetado a la pared.

Français

1 Percez avec précaution à travers la cloison un trou de diamètre 6 mm (1/4") à la hauteur désirée.

Insérez un ancrage pour cloison sèche (cloison sèche) ou une cheville (cloison brique) dans le trou.

2 Placez le crochet pour peignoir contre la cloison en alignement avec le trou percé et serrez bien la vis.

3 Emboîtez le capuchon d'extrémité sur le crochet pour peignoir.

Français

4 Assurez-vous que le crochet pour peignoir est bien fixé à la cloison.