

English

1 Carefully drill 2 x 6mm (1/4") or 12mm (1/2") diameter holes through the wall with a horizontal distance of 21mm (7/8") between the holes.

Insert 2 wall toggles (drywall)
OR wall plugs (brick) into holes.

2 Insert Mounting Bracket onto wall. Fasten screws tightly.

3 Place Toilet Roll Holder onto mounting bracket and tighten grub screw.

4 Ensure Toilet Roll Holder is tightly fastened to the wall.

Español

1 Taladrar cuidadosamente 2 agujeros de 6mm (1/4") o de 12mm (1/2") de diámetro en la pared a una distancia horizontal de 21mm (7/8") entre agujeros.

Introducir 2 anclajes (placa de yeso) O tarugos (pared de ladrillo) en los agujeros.

2 Instalar la ménsula de montaje en la pared. Sujetar bien los tornillos.

3 Colocar el porta papel higiénico sobre la ménsula y ajustar el tornillo prisionero.

4 Asegurarse de que el porta papel higiénico esté bien sujetado a la pared.

Français

1 Percez avec précaution à travers la cloison deux trous de diamètre 6 mm (1/4") ou 12 mm (1/2") à une distance horizontale de 57 mm (2-1/4") entre les trous.

Insérez deux ancrages pour cloison sèche (cloison sèche) OU deux chevilles (cloison brique) dans le trou.

2 Insérez le support de fixation dans la cloison. Serrez bien les vis.

3 Placez le porte-rouleau de papier toilette sur le support de fixation et serrez la vis sans tête.

Français

4 Assurez-vous le porte-rouleau de papier toilette est bien fixé à la cloison.
