

---

**1** Carefully drill 2 x 6mm (1/4") or 12mm (1/2") diameter holes through the wall with a horizontal distance of 57mm (2-1/4") between the holes.

Insert 2 wall toggles (drywall) OR wall plugs (brick) into holes.

---

**2** Align Soap Dish with drilled holes and insert screws.

Make sure the Soap Dish is level.

Fasten screws tightly.

---

**3** Place Cover Buttons over screws.

---

---

## English

---

- 4** Ensure Soap Dish is tightly fastened to the wall.
-

---

Español

---

**1** Taladrar cuidadosamente 2 agujeros de 6mm (1/4") o de 12mm (1/2") de diámetro en la pared a una distancia horizontal de 57mm (2-1/4") entre agujeros.

Introducir 2 anclajes (placa de yeso) O tarugos (pared de ladrillo) en los agujeros.

---

**2** Alinear la jabonera con los agujeros taladrados e introducir los tornillos.

Asegurarse de que la jabonera esté nivelada.

Sujetar bien los tornillos.

---

---

**3** Colocar los botones de tapa sobre los tornillos.

---

**4** Asegurarse de que la jabonera esté bien sujeta a la pared.

---

---

## Français

---

**1** Percez avec précaution à travers la cloison deux trous de diamètre 6 mm (1/4") ou 12 mm (1/2") à une distance horizontale de 57 mm (2-1/4") entre les trous.

Insérez deux ancrages pour cloison sèche (cloison sèche) OU deux chevilles (cloison brique) dans le trou.

---

**2** Placez le porte-savon en alignement avec les trous percés et insérez les vis.

Assurez-vous que le porte-savon est bien horizontal. Serrez bien les vis.

---

---

**3** Placez les caches sur les vis.

---

**4** Assurez-vous que le porte-savon est bien fixé à la cloison.

---