

---

English

---

**1** Carefully drill 2 x 6mm (1/4") or 12mm (1/2") diameter holes through the wall with a horizontal distance of 15mm (5/8") between the holes.

Insert 2 wall toggles (drywall)  
OR wall plugs (brick) into holes.

---

**2** Attach Mounting Bracket to the wall and insert screws.

Fasten screws tightly.

---

**3** Place Robe Hook onto mounting bracket and fasten tightly with the grub screw.

---

**4** Ensure Robe Hook is tightly fastened to the wall.

---

---

Español

---

**1** Taladrar cuidadosamente 2 agujeros de 6mm (1/4") o de 12mm (1/2") de diámetro en la pared a una distancia horizontal de 15mm (5/8") entre agujeros.

Introducir 2 anclajes (placa de yeso) O tarugos (pared de ladrillo) en los agujeros.

---

**2** Sujetar la ménsula a la pared e introducir los tornillos.

Ajustar bien los tornillos.

---

**3** Colocar el gancho para ropa en la ménsula y sujetarlo bien con el tornillo prisionero.

---

---

Español

---

**4** Asegurarse de que el gancho para ropa esté bien sujetado a la pared.

---

## Français

---

**1** Percez avec précaution à travers la cloison deux trous de diamètre 6 mm (1/4") ou 12 mm (1/2") à une distance horizontale de 15 mm (5/8") entre les trous.

Insérez deux ancrages pour cloison sèche (cloison sèche) OU deux chevilles (cloison brique) dans le trou.

---

**2** Fixez le support de fixation à la cloison et insérez les vis.

Serrez bien les vis.

---

---

## Français

---

**3** Placez le crochet pour peignoir sur le support de fixation et serrez bien la vis sans tête.

---

**4** Assurez-vous que le crochet pour peignoir est bien fixé à la cloison.

---