

English

1 Carefully drill 2 x 6mm (1/4") diameter holes through the wall with a distance of 16mm (5/8") between the holes.

Insert 2 x drywall anchors (drywall) or wall plugs (brick) into holes.

2 Insert wall mounting bracket onto wall using a screwdriver and fasten all screws.

3 Attach Toilet Roll Holder to the mounting bracket and fasten grub screw underneath.

4 Ensure Toilet Roll Holder is tightly fastened to the wall.

Español

1 Taladrar cuidadosamente 2 agujeros de 6mm (1/4") de diámetro en la pared a 16mm (5/8") de distancia.

Introducir 2 anclajes (placa de yeso) o tarugos (pared de ladrillo) en los agujeros.

2 Introducir ménsulas de montaje en la pared usando un destornillador y ajustar todos los tornillos.

3 Conectar el porta papel higiénico a la ménsula de montaje y sujetar el tornillo prisionero por debajo.

Español

4 Asegurarse de que el porta papel higiénico esté bien sujetado a la pared.

Français

1 Percez soigneusement 2 trous de 6 mm (1/4") de diamètre dans le mur, en respectant une distance de 16 mm (5/8") entre les trous.

Insérez 2 ancrages pour cloison sèche (cloison sèche) ou 2 chevilles standard (cloison brique) dans les trous.

2 Insérez le support de fixation murale sur le mur à l'aide d'un tournevis et serrez toutes les vis.

Français

3 Fixez le porte-rouleau de papier toilette au support de fixation et serrez par en dessous la vis sans tête.

4 Assurez-vous que le porte-rouleau de papier toilette est bien fixé au mur.
