
English

1 Carefully drill 2 x 6mm (1/4") diameter holes through the wall with a distance of 52mm (2") between the holes.

Insert 2 x drywall anchors (drywall) or wall plugs (brick) into holes.

2 Insert Soap Dish mounting bracket onto wall using a screwdriver and fasten all screws.

3 Place Soap Dish onto the mounting bracket, fasten both grub screws underneath.

4 Ensure Soap Dish is tightly fastened to the wall.

Español

1 Taladrar cuidadosamente 2 agujeros de 6mm (1/4") de diámetro en la pared a 52mm (2") de distancia.

Introducir 2 anclajes (placa de yeso) o tarugos (pared de ladrillo) en los agujeros.

2 Introducir la ménsula de montaje de la jabonera en la pared usando un destornillador y ajustar todos los tornillos.

3 Ubicar la jabonera sobre la ménsula de montaje y ajustar ambos tornillos prisioneros por debajo.

Español

4 Asegurarse de que la jabonera esté bien sujeta a la pared.

Français

1 Percez soigneusement 2 trous de 6 mm (1/4") de diamètre dans le mur, en respectant une distance de 52 mm (2") entre les trous.

Insérez 2 ancrages pour cloison sèche (cloison sèche) ou 2 chevilles standard (cloison brique) dans les trous.

2 Insérez le support de fixation murale du porte-savon sur le mur à l'aide d'un tournevis et serrez toutes les vis.

Français

3 Fixez le porte-savon au support de fixation et serrez par en dessous les deux vis sans tête.

4 Assurez-vous que le porte-savon est bien fixé au mur.
