

English

---

**1** Carefully drill 2 x 6mm (1/4") diameter holes through the wall with a vertical distance of 15mm (5/8") between the holes.

Insert 2 x drywall anchors (drywall) or wall plugs (brick) into holes.

---

**2** Insert Robe Hook mounting bracket onto wall using a screwdriver and fasten all screws.

---

**3** Place Robe Hook onto the mounting bracket and fasten the grub screw on top.

---

**4** Ensure Robe Hook is tightly fastened to the wall.

---

Español

---

**1** Taladrar cuidadosamente 2 agujeros de 6mm (1/4") de diámetro en la pared a una distancia vertical de 15mm (5/8") entre agujeros.

Introducir 2 anclajes (placa de yeso) o tarugos (pared de ladrillo) en los agujeros.

---

**2** Introducir la ménsula de montaje del gancho en la pared usando un destornillador y ajustar todos los tornillos.

---

**3** Ubicar el gancho para ropa sobre la ménsula de montaje y ajustar el tornillo prisionero arriba.

---

Español

---

**4** Asegurarse de que el gancho para ropa esté bien sujetado a la pared.

---

---

## Français

---

**1** Percez soigneusement 2 trous de 6 mm (1/4") de diamètre dans le mur, en respectant une distance verticale de 15 mm (5/8") entre les trous.

Insérez 2 ancrages pour cloison sèche (cloison sèche) ou 2 chevilles standard (cloison brique) dans les trous.

---

**2** Insérez le support de fixation murale du crochet pour peignoir sur le mur à l'aide d'un tournevis et serrez les vis.

---

## Français

---

**3** Fixez le crochet pour peignoir au support de fixation et serrez par en dessous la vis sans tête.

---

**4** Assurez-vous que le crochet pour peignoir est bien fixé au mur.

---