
English

1 Carefully drill 2 x 6mm (1/4") diameter holes through the wall with a distance of 22mm (7/8") between the holes.

Insert 2 x drywall anchors (drywall) or wall plugs (brick) into holes.

2 Insert wall mounting brackets onto wall using a screwdriver and fasten all screws.

3 Attach Robe Hook to the mounting bracket and fasten the grub screw underneath.

4 Ensure Robe Hook is tightly fastened to the wall.

Español

1 Taladrar cuidadosamente 2 agujeros de 6mm (1/4") de diámetro en la pared a 22mm (7/8") de distancia.

Introducir 2 anclajes (placa de yeso) o tarugos (pared de ladrillo) en los agujeros.

2 Introducir ménsulas de montaje en la pared usando un destornillador y ajustar todos los tornillos.

3 Conectar el gancho para ropa a la ménsula y ajustar el tornillo prisionero debajo.

Español

4 Asegurarse de que el gancho para ropa esté bien sujetado a la pared.

Français

1 Percez soigneusement 2 trous de 6 mm (1/4") de diamètre dans le mur, en respectant une distance verticale de 22 mm (7/8") entre les trous.

Insérez 2 ancrages pour cloison sèche (cloison sèche) ou 2 chevilles standard (cloison brique) dans les trous.

2 Insérez le support de fixation murale sur le mur à l'aide d'un tournevis et serrez les vis.

Français

3 Fixez le crochet pour peignoir au support de fixation et serrez par en dessous la vis sans tête.

4 Assurez-vous que le crochet pour peignoir est bien fixé au mur.
