

## English

---

**1** Carefully drill 2 x 6mm (1/4") diameter holes through the wall with a distance of 21mm (7/8") between the holes.

Insert 2 x drywall anchors (drywall) or wall plugs (brick) into holes.

---

**2** Insert wall mounting brackets onto wall using a screwdriver and fasten all screws.

---

**3** Attach Hand Towel Holder to the mounting bracket and fasten the grub screw underneath.

---

**4** Ensure Hand Towel Holder is tightly fastened to the wall.

---

---

Español

---

**1** Taladrar cuidadosamente 2 agujeros de 6mm (1/4") de diámetro en la pared a 21mm (7/8") de distancia.

Introducir 2 anclajes (placa de yeso) o tarugos (pared de ladrillo) en los agujeros.

---

**2** Introducir ménsulas de montaje en la pared usando un destornillador y ajustar todos los tornillos.

---

**3** Conectar el toallero a la ménsula y ajustar el tornillo prisionero debajo.

---

**4** Asegurarse de que el toallero esté bien sujetado a la pared.

---

## Français

---

**1** Percez soigneusement 2 trous de 6 mm (1/4") de diamètre dans le mur, en respectant une distance de 21 mm (7/8") entre les trous.

Insérez 2 ancrages pour cloison sèche (cloison sèche) ou 2 chevilles standard (cloison brique) dans les trous.

---

**2** Insérez le support de fixation murale sur le mur à l'aide d'un tournevis et serrez les vis.

---

---

## Français

---

**3** Fixez le porte-essuie-mains au support de fixation et serrez par en dessous la vis sans tête.

---

**4** Assurez-vous que le porte-essuie-mains est bien fixé au mur.

---