

English

- 1** *Ensure there is sufficient support installed in-wall.
*Ensure there is 13mm (1/2") exposed thread.

Install 2x6 Cross Brace within the wall between the wall studs.

Drill 22mm (7/8") hole through cross brace.

- 2** Install the 1/2" NPT cold water supply. Ensure pipe is secured to Cross Brace.

Important: 1/2" NPT thread must not exceed 13mm (1/2") from the face of the finished wall.

-
- 1** *Asegurarse de que haya suficiente soporte instalado dentro de la pared.
*Asegurarse de que haya 13mm (1/2") de rosca expuesta.

Instalar una cruceta transversal de 2x6 dentro de la pared, entre los tacos de la pared.

Taladrar un agujero de 22mm (7/8") a través de la cruceta.

-
- 2** Instalar el suministro de agua fría NPT de 1/2". Asegurarse de que la tubería esté bien sujeta a la cruceta.
-

Importante: La rosca NPT de 1/2" no debe superar una distancia de 13mm (1/2") de la cara de la pared terminada.

Français

1 *Assurez-vous que le support installé dans le mur est suffisant.

*Assurez-vous que la longueur du filetage exposé est de 13 mm (1/2").

Installez une entretoise transversale 2x6 dans la cloison entre les montants.

Percez un trou de 22 mm (7/8") dans l'entretoise.

2 Installez l'alimentation d'eau froide sur le raccord NPT 1/2". Assurez-vous que le tuyau est bien fixé à l'entretoise.

Français

Important: Le raccord NPT ne doit pas dépasser de plus de 13 mm (1/2") de la surface de la cloison finie.